

Mini Pen DVR Use Manul

Introduction

our mini pen DVR is deal for both spy camera & hidden camera, small enough to conceal almost anywhere!

Wherever you place your mini camera, you'll know for sure that you won't miss anything

What your mini interview recorder includes?

- Mini pen DVR
- USB cable
- Adaptor
- Use manul
- CD for play software



Features

- Dimension:150mm*15mm*15mm
- Weight:30g
- Tiny size makes it ideal for a variety of uses.
- It's great for use as a hidden cam, spy cam , etc.
- Real time recording in AVI video format
- Color video with voice lets you clearly see who's there & hear what they say.
- Place it up high or conceal it down low. With built-in rechargeable 1 battery so there's no long cord for you to hide.
- Internal memory: 2 GB
- Playback video on PC

Camera Technical Parameter

- Video compression : AVI video format
- Voice recording: Yes
- Internal memory: Yes
- Flash: 2 GB or 4GB
- Video file size; >500KB per min
- Recording mode :continuous recording until memory is full or manually off
- Adaptor type: USB adaptor charging cable
- Battery type : Lithium-ion
- Battery use time : about 3h

A Quick Look at your Mini Pen DVR



1.Camera

2.MIC

3.USB

4.Record And Power Light

5.Power on/off

6.Reset

Starting your Mini Pen DVR

Step 1:

Press the power switch, the light turns to yellow, then wait for about **12** seconds, it will turn to blue automatically, that reflects that the pen DVR begins recording.

Step 2:

When finish recording, Press the switch again (quick press, if more than 5 seconds, the power will be off, no light on), it will begin to save data, at this time, the light turns to yellow, reflects that the pen DVR is at sleeping status (that means do not kinescope or shut down neither).

Step 3:

If need to kinescope again, press the switch once more, then wait for the light turn to blue again, then you can continue to record, when finish recording, press the switch, the light will turn to yellow again.

Step 4:

Hold down the switch for 5s, then the power switch is off, after shutting down the pen DVR, there is no guide light.

Step 5:

It will turn off itself when the battery has been used up. And will save the kinescoped files before automatically shutting down.

How to charge

When you can't start the pen DVR, it needs charging, you can just connect it directly to computer via USB, the yellow light will glitter, it is charging, when the yellow light keeps on, that means the battery is fully charged. Besides, you can use the adaptor to charge, we advise use adaptor to charge.

Brief introduction

1. The fewest mini DVR in the world which conceals in the pen. And the first mini pen DVR with the function of both kinescope and record.
2. The high fidelity microphone can record the sound around 15 m². And the high clear kinescope can help the police and court to get evidence.
3. Suitable for any computer and electron device with USB port. USB2.0 standard port, need no drive or circumscribed electric power source neither.

4. 2 million pixels for the camera.

Connect to PC with USB cable

1. Connect the machine to the computer with USB cable. The machine is in the state of charging while the yellow light is twinkling. (You can also directly charge the camera using an adaptor accorded with the specifications of USB). Charging 2 hours is necessary.
2. Function as removable disk when connect the camera to PC, playback the video files stored flash via the computer. (Free download the codec http://www.majorgeeks.com/K-Lite_Codec_Pack_Full_d4844.html).
3. The paly software is available in the CD.

FAQ

Q : Can the video file which is recording be stored if the battery is out suddenly during using?

A : Don't worry. If the battery use off suddenly it will store the recording video files before it turns off.

Q : How to deal with the situation of system halted?

A : Please use "RESET" button then push the on/off switch, so it will work again.

Q : Which form can be chosen to format?

A : Please use form "FAT" to format.

Attention

1. Do not switch "RESET" button when the machine is recording, otherwise the data won't be saved.
2. Do not keep on pressing the switch before the light turn to blue (it needs about **12** seconds) before recording, or else system halted will probably appear.